

INNOPOL® PP CS 1-3260

Polypropylene Homopolymer

Inno-Comp Ltd.

Message:

INNOPOL® CS 1-3260 is a 55 % chalk-filled polypropylene homopolymer compound /PP-H KD55 (ISO 1043)/.

INNOPOL® CS 1-3260 is developed for producing injection moulded components for household equipments.

General Information			
Filler / Reinforcement	Chalk filler, 55% filler by weight		
Features	Homopolymer		
Uses	Household goods		
Appearance	Available colors		
	Natural color		
Forms	Particle		
Processing Method	Injection molding		
Resin ID (ISO 1043)	PP-H KD55		
Physical	Nominal Value	Unit	Test Method
Density (23°C)	1.39	g/cm ³	ISO 1183
Melt Mass-Flow Rate (MFR) (230°C/2.16 kg)	7.0	g/10 min	ISO 1133
Mechanical	Nominal Value	Unit	Test Method
Tensile Modulus	3300	MPa	ISO 527-2/1
Tensile Stress (Yield)	21.0	MPa	ISO 527-2/50
Tensile Strain (Yield)	2.0	%	ISO 527-2/50
Flexural Modulus ¹	3850	MPa	ISO 178
Impact	Nominal Value	Unit	Test Method
Charpy Notched Impact Strength			ISO 179/1eA
-20°C	2.1	kJ/m ²	ISO 179/1eA
23°C	3.8	kJ/m ²	ISO 179/1eA
Thermal	Nominal Value	Unit	Test Method
Heat Deflection Temperature (0.45 MPa, Unannealed)	123	°C	ISO 75-2/B
Injection	Nominal Value	Unit	
Drying Temperature	80.0	°C	
Drying Time	2.0	hr	
Suggested Max Moisture	0.070	%	
Rear Temperature	190 - 250	°C	
Middle Temperature	190 - 250	°C	
Front Temperature	190 - 250	°C	
Processing (Melt) Temp	230 - 260	°C	

Mold Temperature	10.0 - 50.0	°C
Injection Rate	Moderate	
Injection instructions		
Hold pressure: 50 to 80 % of actual injection pressure		
NOTE		
1.	2.0 mm/min	

The information and data on this page are provided by manufacturers and document providers. SHANGHAI SUSHENG assumes no legal liability. It is strongly recommended to verify all technical data with material suppliers before final material selection. All rights belong to the original authors. If any infringement occurs, please contact us immediately.

Recommended distributors for this material

Susheng Import & Export Trading Co.,Ltd.

Tel: +86 21 5895 8519

Phone: +86 13424755533

Email: sales@su-jiao.com

No. 215, Lianhe North Road, Fengxian District, Shanghai, China

