

# Mediprene® 502584M

Thermoplastic Elastomer

ELASTO

## Message:

ELASTO have developed a range of Mediprene thermoplastic elastomers (TPE) for plunger seals in single-use syringes.

The TPE seal, which is mounted on the end of the plunger, needs to provide a leakproof seal with the syringe barrel. As ease of use for the medical practitioner and patient comfort are also key requirements, the seal helps to optimize plunger movement for accurate dosage control and ease of injection.

### Regulatory compliance

Originating from medical raw materials with high biocompatibility status and compounded under clean conditions, Mediprene TPEs are the material of choice for medical customers who want to maximize the probability that their devices will pass relevant medical tests.

The raw materials in these compounds comply with food contact norms like FDA 21CFR and 2011/10 EC. All polymers used have passed tests according to USP class VI and the paraffinic oil has passed the USP Mineral Oil NSF H1, reg 125038 and also the European Pharmacopeia, liquid paraffin.

Mediprene TPEs are latex free, which reduces the risk of allergic reactions. Representative grades have passed cytotoxicity tests according to ISO 10993-5 and biocompatibility tests according to USP Class VI.

## General Information

Features	Biocompatible Food Contact Acceptable
----------	--

Uses	Medical/Healthcare Applications
------	---------------------------------

Agency Ratings	EU 2011/10/EC FDA Unspecified Rating ISO 10993 Part 5 USP Class VI
----------------	---

Appearance	Black Colors Available
------------	---------------------------

Processing Method	Extrusion Injection Molding
-------------------	--------------------------------

Physical	Nominal Value	Unit	Test Method
Specific Gravity	0.880	g/cm <sup>3</sup>	ASTM D792
Melt Mass-Flow Rate (MFR) (190°C/2.16 kg)	3.0	g/10 min	ASTM D1238

Hardness	Nominal Value	Unit	Test Method
Durometer Hardness (Shore A, 4.00 mm)	58		ASTM D2240

Mechanical	Nominal Value	Unit	Test Method
Tensile Strength			ASTM D638
--	10.5	MPa	
100% Strain	1.60	MPa	
300% Strain	2.50	MPa	
Tensile Elongation (Break)	800	%	ASTM D638

Elastomers	Nominal Value	Unit	Test Method
Tear Strength	22.5	kN/m	ASTM D624
Injection	Nominal Value	Unit	
Rear Temperature	180 to 220	°C	
Middle Temperature	180 to 220	°C	
Front Temperature	180 to 220	°C	
Mold Temperature	20.0 to 50.0	°C	
Extrusion	Nominal Value	Unit	
Cylinder Zone 1 Temp.	150 to 210	°C	
Cylinder Zone 2 Temp.	150 to 210	°C	
Cylinder Zone 3 Temp.	150 to 210	°C	
Cylinder Zone 4 Temp.	150 to 210	°C	
Cylinder Zone 5 Temp.	150 to 210	°C	

The information and data on this page are provided by manufacturers and document providers. SHANGHAI SUSHENG assumes no legal liability. It is strongly recommended to verify all technical data with material suppliers before final material selection. All rights belong to the original authors. If any infringement occurs, please contact us immediately.

#### Recommended distributors for this material

### Susheng Import & Export Trading Co.,Ltd.

Tel: +86 21 5895 8519

Phone: +86 13424755533

Email: sales@su-jiao.com

No. 215, Lianhe North Road, Fengxian District, Shanghai, China

